

Load Ratings

The **Load Rating** or **Load Index** indicates the load-carrying capacity of a specific tire, or how much weight a tire can safely support. See the chart below for the individual tire load (pounds) that one tire can support; then multiply the kilograms by four (4) to get your maximum load-carrying capacity. Do not install tires with a lower load-carrying capacity than the tires that were installed on your vehicle at the manufacturer.



Load Index	Pounds	Kilograms	Load Index	Pounds	Kilograms
71	761	345	91	1356	615
72	783	355	92	1389	630
73	805	365	93	1433	650
74	827	375	94	1477	670
75	853	387	95	1521	690
76	882	400	96	1565	710
77	908	412	97	1609	730
78	937	425	98	1653	750
79	963	437	99	1709	775
80	992	450	100	1764	800
81	1019	462	101	1819	825
82	1047	475	102	1874	850
83	1074	487	103	1929	875
84	1102	500	104	1984	900
85	1135	515	105	2039	925
86	1168	530	106	2094	950
87	1201	545	107	2149	975
88	1235	560	108	2205	1000
89	1279	580	109	2271	1030
90	1323	600	110	2337	1060